



Equipson, S.A. www.equipson.es support@equipson.es

**BLINDER 464 DMX** 

((

All rights reserved.

**User Manual / Instrucciones de Usuario** 

# **BLINDER 464 DMX**

# **Instructions**

BEFORE OPERATING THIS DEVICE. **READ, UNDERSTAND AND FOLLOW** THESE INSTRUCTIONS. BE SURE TO **SAVE THIS MANUAL FOR FUTURE** REFERENCE.

WARNING -This lumin aire is intended for professional use onlyand does not comply with certain domestic lighting regulations.

### **IMPORTANT NOTES**

- Minimum distance from a lighted object is 1Meter.
- Maximum rated ambient temperature is 45°C.
- Input cable may be subjected to temperatures up to 180°C.
- Maximum rated voltage is 240V.
- 'Normal frequency is 50/60 H z.
- Maximum rated wattage is 500 Watts per lamp.

### SAFETY NOTES

Replace I amp if cracked or thermally deformed.

- The Spot Banks should not be used in explosive orinflammable environments.
- 'Always fit safety wire from luminaire to supporting framework.
- Do not over voltage luminaire.
- Whe connecting to the electrical supply, ensure that the luminaire is effectively earthed, that the supply is at the rated voltage for the lamp, wiring is complete and as shown on the diagram below and that theorrect polarity is observed.

SCREW

LAMP

TERMINA

- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agentor as imilar qualified person in order to avoid a hazard.
- Shields, lenses or ultraviolet screens shall be changed if they have become visibly damaged to filch an extent that their effectiveness is impaired, for example by cracks or deep screeches.
- Always disconnect from the mains, when the device is not in user or before cleaning it.

### **ELECTRICAL CONNECTION**

WARNING -Thi s appliance MUST be earthed.

The supply cables should be connected to an approved plug in accordance with following code:

Wire Colour	Conne ction	n Plug Terminal Marking or Colour		
Green & Yellow	Earth	E Green & Yellow or ⊕		
Blue	Neutral	N Black		
Bro wn	l iv e	I Red		

### LAMP REPLACEMENT (see Fig 1.)

- Disconnect the luminaire from the power supply and allow cooling.
- Undo the 2 screws that hold each lamp-retaining ring that holds the Par lamp.
- Remove wires from the lamp by unscrewing the screw terminals.
- To refit lamp, follow steps 1 to 3 in reverse order.
- Ensure the lamp is seated properly and make sure no wires are trapped before refixing

#### BLINDER 464 DMX User Manual/Manual de uso WORK!

LAMP RETAINING

BLINDER 464 DMX

### **MONTAJE Y AJUSTE**

AVISO - La temp. Máxima es de 180º C - Esta luminaria no es adecuada para montar en superficies

La unidad incorpora un asa de montaje con un aquiero de 12.7 mm de diámetro que permite colocar una garra para montar en truss, etc. Usando el asa, es posible cambiar la orientación del giro.

Tipo	Voltios	Watios
PAR 64 GY 9.5	230 V	500 w

Use lámpara de igual voltage y potencia en el mismo circuito.

### **INSTRUCCIONES DE FUNCIONAMIENTO**

La unidad dispone de un sólo modo.

Modo DMX, le permite interconexionar una serie de unidad es en una cadena, usando un cable estéreo XLR con conector de 3 pines. Así puede controlarlo con una consola estandard DMX.

Configure la dirección DMX con los dip 1-9. El dip 10 no tiene uso. Este efecto utiliza 4 canales de control DMX: El canal 1 controla el brillo de la lámpara 1, los canales 2, 3 y 4 controlan el brillo de las lámpara 2. 3 v 4. Cuando el valor DMX es "0" el brillo es el mínimo, el brillo se incrementa con el valor DMX. Cuando el valor es "255" el brillo es máximo. (Ver figura 2)








DIP switches



Direccionamiento DMX





This symbol on the product or on its packaging indicates that this product shall not be trated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical an electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of amterials will help to conserve natural resources. For more detailed information sabout recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product



## **BLINDER 464 DMX**

**Instrucciones** 

ANTES DE OPERAR CON EL **DISPOSITIVO, LEA, COMPRENDA** Y SIGUA ESTAS INSTRUCCIONES **CONSERVE EL MANUAL PARA FUTURAS REFERENCIAS.** 

AVISO Esta luminaria ha sido diseñada para uso profesional y no cumple ciertas regulaciones de iluminación doméstica.



- Mínima distancia al objeto iluminado: 1 m
- Máxima temperatura amiente: 45° C
- El cable de red debe soportar hasta 180° C
- Máximo voltaie: 240 V
- Frecuencia de uso: 50/60 Hz
- Máxima potencia por lámpara: 500 W

### NOTAS DE SEGURIDAD

- Sustituya la lámpara en caso de rotura o deformación por calor.
- La unidad no debe ser usada en ambiente inflamable o explosivos.
- Coloque un cable de seguridad para soportar la unidad.
- No sobrealimente de tensión la unidad
- Cuando conecte la alimentación, asegúrese que está conectada a tierra y que el valor de tensión es el correcto. Cablee la unidad de acuerdo al diagrama inferior, observando la polaridad.

ARO DE RETENCION

- Si el cable externo se daña, debe ser sustituido exclusivamente por el fabricante o su servicio técnico para evitar riesgos.

TORNILLO

TERMINAL

- Pantallas, lentes, etc deben ser sustituidas cuando se aprecien daños visibles o pérdida de eficacia , por ejemplo con rayaduras o golpes.
- Desconecte siempre la alimentación si no va usar el dispositivo.

### **CONEXION ELECTRICA**

AVISO - Esta unidad debe ser conectada a tierra

Los cables de alimentación deben ser conectados de la siguiente manera:

Color del cable	Conexión	Marca en el terminal o color
Amarillo / Verde	Tierra	E Amarillo / Verde ⊈
Azul	Neutro	N Azul
Marrón	Fase	L Marrón

### SUSTITUCION DE LA LAMPARA (Ver Fig. 1)

- 1. Desconecte la unidad de la red v deie que se enfríe.
- 2. Destornille los dos tornillos que retienen cada lámpara.
- 3. Retire los cables, destornillando cada terminal de la lámpara.
- 4. Para colocar la lámpara sigua los pasos 1 a 3 en orden inverso
- 5. Asegúrese que la lámpara está bien colocada y los cables no están pinzados.

### MOUNTING AND ADJUSTMENT

WARNING-Max Temp=180℃ -Th is luminaire is not suitable for mounting on flammable surfaces. The luminai re is supplied with a yoke with a 12.7mm diameter hole allowing the luminaire to be fitted with a hook clamps in order that it can be mounted on a 5cm tube. Using the "T" bar on the side, the tilt angle can be adjusted.

### **LAMP TYPES**

Standard lamp types are shown in the box below.

Туре	Voltage	Wattage
PAR 64 GY 9,5	230 V	500 W

N.B. Always use bulbs of identical Voltage and Wattage in the same circuit.

There is only one mode to operate this luminaire.

### Operating instruction







DMX OUT DMX IN

DIP switches


#### DMX MODE

DMX mode allow to link serial unites into a chain with DMX linking cable-stereo cable with 3-pin XLR-plug and connnector. Then you can control them with a standard DMX controller.

Set DMX address via DIP 1~9 switches. DIP 10 is invalid. This luminare use 4 channells to control lamps' brightness. Channel 1 control the lamp1 brightness, channel 2, 3, 4 control the lamp2,3,4's brightness as well. When DMX value is "0",lamps' brightness are min. . The brightness is increased when the DMX value is increased. When DMX value is "255". lamps' bright are max..(See Fig 2)



DMX Address





Este símbolo en su equipo o embalaje, indica que el presente producto no puede ser tratado como residuos domésticos normales, sino que deben entregarse en el correspondiente punto de recogida de equipos electrónicos y eléctricos. Asegurándose de que este producto es desechado correctamente, Ud. está ayudando a prevenir las consecuencias negativa: para el medio ambiente y la salud humana que podrían derivarse de la incorrecta manipulación de este producto. EL reciclaie de materiales ayuda a conservar las reservas naturales. Para recibir más información, sobre el reciclaje de este producto, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el product

WORK !

BLINDER 464 DMX